



Part #	Description	Quantity in Planogram
E217	Entry Door Holder - Zinc "T" 4"	3
E218	Entry Door Holder - Zinc "T" 6"	3
E221	Grab Handle - Chrome 10"	2
E222	Grab Handle - Plastic - White. 9- 1/2" overall, 7- 7/8" between screw hole centers.	2
E223	Grab Handle - Plastic - Black 9- 1/2" overall, 7- 7/8" between screw hole centers.	2
E224	Entry Door Holder - Self Closing Stainless Steel "T" 4"	3
E225	Entry Door Holder - Stainless Steel 3 3/4"	3
E226	Entry Door Holder - Self Closing Stainless Steel "T" 6"	3
E227	Entry Door Bumper - Black Rubber - 2 1/4"	3
E229	Entry Door Bumper - White Plastic - 2 7/8"	3
E231	Entry Door Holder - Plastic "T" - 3 1/2" - White	3
E232	Entry Door Holder - Plastic "T" - 3 1/2" - Black	3
E233	Entry Door Holder - Plastic "T" - 3 1/2" - Col White	3
E235	Entry Door Holder - Plastic "T" - 6" - White	3
E236	Entry Door Holder - Plastic "T" - 6" - Black	3
E237	Entry Door Holder - Plastic - "T" 6" - Col White	3
E238	Entry Door Holder - Plastic - "T" 6" - Grey	3
E241	Entry Door Holder - Plastic Clip - 3" - White	3
E242	Entry Door Holder - Plastic - clip only - White	3
E250	Entry Door Holder - Plastic - 90 Degree - White	3
E251	Entry Door Holder - Metal Plunger - 3"	2
E255	Entry Door Holder - Metal Plunger - 3" Angled	2
E260	Entry Door Holder - Rubber Socket	3
E273	Entry Door Holder - 90 Degree - Zinc	3
E275	Entry Door Holder - 45 Degree - Stainless Steel	3
E277	Entry Door Holder - 90 Degree - Stainless Steel	3
E278	Entry Door Holder - Plastic - 90 Degree - Black	3
E285	Screen Door Latch - Amerimax - Right Hand	3
E287	Screen Door Latch - Amerimax - Left Hand	3
E291	Bullet Latch	3
E295	Screen Door Latch - Phillips - Right Hand	3
E297	Screen Door Latch - Phillips - Left Hand	3