

	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22
1	Entry Door Hardware																					
2																						
3																						
4																						
5																						
6	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o
7																						
8																						
9																						
10																						
11	1-1	1-2	1-3	1-4	1-5																	
12	E285	E295	E241	E229	E227																	
13	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o
14																						
15																						
16																						
17	2-1	2-2	2-3	2-4	2-5																	1-6
18	E287	E297	E228	E242	E260																	E221
19	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o
20																						
21	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o
22																						
23																						
24																						
25																						
26																						
27	3-1	3-2	3-3	3-4	3-5																	
28	E277	E278	E231	E233	E232																	
29	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o
30																						
31																						
32																						
33																						
34																						
35	4-1	4-2	4-3	4-4	4-5	4-6																
36	E250	E273	E217	E224	E225	E251																
37	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o
38																						
39																						
40																						
41																						
42																						
43																						
44	5-1	5-2	5-3	5-4	5-5	5-6	5-7															5-8
45	E275	E235	E237	E236	E238	E226	E218															E223
46	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o	o o o o
47																						
48																						
49																						
50																						

Part #	Description	Quantity in Planogram
E217	Entry Door Holder - Zinc "T" 4"	3
E218	Entry Door Holder - Zinc "T" 6"	3
E221	Grab Handle - Chrome 10"	2
E222	Grab Handle - Plastic - White. 9- 1/2" overall, 7- 7/8" between screw hole centers.	2
E223	Grab Handle - Plastic - Black 9- 1/2" overall, 7- 7/8" between screw hole centers.	2
E224	Entry Door Holder - Self Closing Stainless Steel "T" 4"	3
E225	Entry Door Holder - Stainless Steel 3 3/4"	3
E226	Entry Door Holder - Self Closing Stainless Steel "T" 6"	3
E227	Entry Door Bumper - Black Rubber - 2 1/4"	3
E228	Entry Door Bumper 1"	2
E229	Entry Door Bumper - White Plastic - 2 7/8"	3
E231	Entry Door Holder - Plastic "T" - 3 1/2" - White	3
E232	Entry Door Holder - Plastic "T" - 3 1/2" - Black	3
E233	Entry Door Holder - Plastic "T" - 3 1/2" - Col White	3
E235	Entry Door Holder - Plastic "T" - 6" - White	3
E236	Entry Door Holder - Plastic "T" - 6" - Black	3
E237	Entry Door Holder - Plastic - "T" 6" - Col White	3
E238	Entry Door Holder - Plastic - "T" 6" - Grey	3
E241	Entry Door Holder - Plastic Clip - 3" - White	3
E242	Entry Door Holder - Plastic - clip only - White	3
E250	Entry Door Holder - Plastic - 90 Degree - White	3
E251	Entry Door Holder - Metal Plunger - 3"	2
E260	Entry Door Holder - Rubber Socket	3
E273	Entry Door Holder - 90 Degree - Zinc	3
E275	Entry Door Holder - 45 Degree - Stainless Steel	3
E277	Entry Door Holder - 90 Degree - Stainless Steel	3
E278	Entry Door Holder - Plastic - 90 Degree - Black	3
E285	Screen Door Latch - Amerimax - Right Hand	3
E287	Screen Door Latch - Amerimax - Left Hand	3
E295	Screen Door Latch - Phillips - Right Hand	3
E297	Screen Door Latch - Phillips - Left Hand	3