

Part #	Description	Quantity in Planogram
S125	Black Rocker Switch, 40A w/Plate	2
S141	Black Contoured Switch, 40A	2
S221	Black Rocker Switch, 20 A, 4 X Terminal	2
S225	Black Rocker Switch, 20 A, 6 Terminal	2
S241	White w/Red Rocker Switch, 10 A	2
S245	Black w/Red Rocker Swtch,125 VAC	2
S247	Black w/Red Rocker Swtch,10 A	2
S261	Black Rocker Switch, 10	2
S265	White Rocker Switch w/Gold text,10A	2
S269	Black Rocker Switch w/Silver text,10A	2
S273	Brown Rocker Switch w/Gold text, 10 A, On/Off	2
S279	Ivory Rocker Switch w/Gold text,10A	2
S321	Black Rocker Switch, 10 A	2
S341	Black Rocker Switch, 10 A, Momentary On/Off/Momentary On	2
S345	White Rocker Switch, 10 A	2
S361	Black w/Red	2
S365	White w/Red Indicator Lights	2
S381	White, Single	2
S385	Black, Single	2
S431	Black Rocker Switch	2
S435	White Rocker Switch	2
S471	Black Rocker Switch, 5 A	2
S475	White Rocker Switch, 5 A	2
S481	Black W/Red Rocker Switch, 20 A	2
S521	Contoured Wall Switch, Black, Single	2
S531	Contoured Wall Switch, White, Single	2
S533	Contoured Wall Switch, White, Double	2
S651	Wall Plate Switch, Single, 3.53" x 2.39"	2
S652	Wall Plate Switch, Black, Single, 3.53" x 2.39"	2
S653	Wall Plate Switch, White, Single, 3.53" x 2.39"	2
S655	Wall Plate Switch, Double, 3.53" x 3"	2
S656	Wall Plate Switch, Black, Double, 3.53" x 3"	2
S657	Wall Plate Switch, White, Double, 3.53" x 3"	2
S660	Wall Plate Switch, Black, Triple, 3.53" x 4"	2